



## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
NEXIA	ENGINE SOHC	UNLEAD 1.5L			√	√	√	√		
		UNLEAD 1.8L			√	√	√			
		LEAD 1.5			√	√	√	√		
		1.5(rus)			√	√	√	√		
	ENGINE DOHC	UNLEAD 1.5L			√	√	√	√		
		LEAD 1.5L			√	√	√	√		
	AUTOMATIC TRANSAXLE				√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√			
SRS-AIRBAG				√	√					
NEW-NEXIA	01. ENGINE CONTROL	01.1.5 SOHC			√	√	√	√		1.CRANK ANGLE TEC LEARN 2.EVAP.LEAK 3.ECU
		02.1.6 SOHC			√	√	√	√		1.EVAP.LEAK 2.ADAPTION RESET
	02. AUTOMATIC TRANSAXLE				√	√	√			
	03. ANTI-LOCK BRAKE SYSTEM				√	√	√			
NEW-PRINCE	ENGINE SOHC				√	√	√	√		
	ENGINE DOHC				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√		√	
NEW-BROUGHAM	ENGINE SOHC				√	√	√	√		
	ENGINE DOHC				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√		√	
LANOS	ENGINE SOHC	1.3L			√	√	√	√		
		1.5L			√	√	√	√		
	ENGINE DOHC	1.5L			√	√	√	√		
		1.6L			√	√	√	√		

## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
LANOS	AUTOMATIC TRANSAXLE				√	√	√			
	ANTI-LOCK BRAKE SYSTEM	01.DELPHI			√	√	√	√		
		02.BOSCH			√	√	√	√		
	SRS-AIRBAG				√	√				
NEW-LANOS	01. ENGINE CONTROL	01.1.5 SOHC			√	√	√	√		1.CRANK ANGLE TEC LEARN 2.EVAP.LEAK 3.ECU
	02. AUTOMATIC TRANSAXLE				√	√	√			
	03. ANTI-LOCK BRAKE SYSTEM				√	√	√			
NUBIRA	ENGINE SOHC	1.5L			√	√	√	√		
	ENGINE DOHC	1.5L			√	√	√	√		
		1.8L			√	√	√	√		
		2.0L			√	√	√	√		
	AUTOMATIC TRANSAXLE				√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√			
	SRS-AIRBAG				√	√	√			
LEGANZA	ENGINE SOHC	1.8L			√	√	√	√		
		LPG			√	√				
		2.0L			√	√	√	√		
	ENGINE DOHC	1.8L			√	√	√	√		
		2.0L			√	√	√	√		
		2.2L			√	√	√	√		
		LPG			√	√				
	AUTOMATIC TRANSAXLE	LPG			√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√	√	Air Bleed
	SRS-AIRBAG				√	√	√			
		01.0.8L			√	√	√	√		

## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions								
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions		
MATIZ/SPARK	ENGINE CONTORL	02.1.0L			√	√	√	√				
		03.LEAD			√	√	√					
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√				
	SRS-AIRBAG				√	√						
NUBIRI II	ENGINE SOHC	2.0 L			√	√	√	√				
	ENGINE DOHC	1.5 L			√	√	√					
		1.6 L				√	√	√				
		2.0 L				√	√	√	√			
	AUTOMATIC TRANSAXLE				√	√	√					
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√				
SRS-AIRBAG				√	√	√						
MAGNUS	ENGINE CONTROL	GASOLINE(L4)			√	√	√	√				
		XK(SIEMENS L6)			√	√	√					
		LPG				√	√					
	AUTOMATIC TRANSAXLE	GASOLINE(~2002MY)				√	√	√	√			
		GASOLINE(2002MY~)				√	√	√	√			
		LPG				√	√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√				
	SRS-AIRBAG				√	√						
ISC				√	√	√	√					
REZZO/TACUMA	ENGINE CONTROL	UNLEADED			√	√	√	√				
		LPG	NIKKI LPG ENGINE			√	√	√				
			LPG				√	√				
		GASOLINE BEFORE 2005	01.SOHC				√	√	√	√		
			02.1.6 DOHC				√	√	√	√		
			03.1.8DOHC				√	√	√	√		
		GASOLINE AFTER 2005	01.SOHC				√	√	√	√		
			02.1.6 DOHC				√	√	√	√		
			03.1.8DOHC				√	√	√	√		
							√	√	√	√		

## Daewoo **V26.30** Diagnostics List( Note: For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
			04.2.0 DOHC		√	√	√	√		
	AUTOMATIC TRANSAXLE	GASOLINE			√	√	√	√		
		LPG			√	√	√	√		
		4HP16				√	√	√	√	
		SAISIN				√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
	SRS-AIRBAG				√	√	√			
KALOS/AVEO(~05 MY)	ENGINE CONTROL	SOHC			√	√	√	√		
		1.2 SOHC (SIEMENS)			√	√	√	√		
		1.5 SOHC (DELPHI)				√	√	√	√	
		1.6 SOHC (DELPHI)				√	√	√	√	
	AUTOMATIC TRANSAXLE				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM					√	√	√	√	
	SRS-AIRBAG				√	√				
DAMAS/RABO	ENGINE CONTROL				√	√	√	√		
LACETTI/OPTRA/EXCELLE(~05)	ENGINE CONTROL	1.5L				√	√	√		
		1.6L				√	√	√	√	
	AUTOMATIC TRANSAXLE					√	√	√	√	
	ANTI-LOCK BRAKE SYSTEM					√	√	√	√	
	SRS-AIRBAG					√	√			
KALOS/AVEO(06~)	ENGINE CONTROL			√	√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
	SRS-AIRBAG				√	√				
LACETTI/OPTRA/	ENGINE CONTROL	1.5 DOHC (SIEMENS)				√	√	√	√	
		1.6 DOHC (SIEMENS)				√	√	√		
		2.0L DIESEL				√	√			
		AISIN TCU (GASOLINE)			√	√	√	√	√	

## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions							
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions	
EXCELLE(06~)	AUTOMATIC TRANSAXLE	AISIN TCU (DIESEL)			√	√	√			LEARNING DATA RESET	
	ANTI-LOCK BRAKE SYSTEM			√	√	√	√	√			
	SRS-AIRBAG				√	√					
MATIZ(M200)	ENGINE CONTROL	0.8 SOHC			√	√	√				
		0.8 SOHC KOBD(2007MY)			√	√	√				
		1.0 SOHC(EURO-II)				√	√	√			
		1.0 SOHC(EURO-III&IV)				√	√	√			
	AUTOMATIC TRANSAXLE				√	√	√	√			
	ANTI-LOCK BRAKE SYSTEM					√	√	√			
	SRS-AIRBAG					√	√				
MATIZ(M300)/SPARK	01.POWER TRAIN	01.ENG.CONTROL MOD.(ECU-D52)				√	√	√	√	1.ADAPTION RESET 2.EVAP.LEAK	
		02.LPG CONTROL MOD.(ICM-LPGI)					√	√	√		
		03.A/T CONTROL MODULE					√	√	√		
	02.CHASSIS	01.BRAKE CONTROL MODULE(EBCM)					√	√	√		1.SAS SENSOR ZERO SETTING 2.WRITE VIN
		03.BODY	01.AIRBAG CONTROL MODULE(SDM)				√	√	√		1.NEW SDM APPLIED SETUP 2.SDM RESET 3.WRITE VIN
			02.INS.CLUSTER CTRL MOD(IPC)				√	√	√		
	ENGINE CONTROL		GASOLINE 1.8L				√	√	√		LEARNING DATA RESET
		GASOLINE 2.0L/2.5L				√	√	√		LEARNING DATA RESET	
		LPI(EMS ECU)				√	√	√	√		
		LPI(IFB ECU)				√	√	√	√		

## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
<b>TOSCA/EPICA</b>		LPG 2.0L(MAIN)			√	√	√			LEARNING DATA RESET
		LPG 2.0L(INTERFACE)			√	√	√			
		2.0L DIESEL			√	√	√			LEARNING DATA RESET
	AUTOMATIC TRANSAXLE	AISIN 4 GEAR(GAS 1.8L)			√	√	√			
		AISIN 4 GEAR(LPG 2.0L)			√	√	√			
		AISIN 5GEAR(GAS 2.0/2.5L)			√	√	√			
		AISIN TCU(DIESEL)			√	√	√			
	ANTI-LOCK BRAKE SYSTEM				√	√	√			
	SRS-AIRBAG			√	√	√	√			
	ISU				√	√	√			
LACETTI PREMIERE/CRUZE	01. ENGINE CONTROL	01.ECM-GEN3 1.6D&1.8D			√	√		√		
		02.ECM-DIESEL			√	√	√	√		
		03.ECM-FAM 1			√	√				
	02. AUTOMATIC TRANSAXLE	01.TCM-GF6			√	√		√		
	03.CHASSIS	01.ABS			√	√				
<b>GENTRA</b>	ENGINE CONTROL	1.2 SOHC (SIEMENS)			√	√	√			
		1.6 DOHC (DELPHI)			√	√	√			
		1.5 SOHC		√	√	√	√	√		
	AUTOMATIC TRANSAXLE			√	√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM				√	√	√	√		
	SRS-AIRBAG			√	√	√	√			
<b>STATEMAN</b>	ENGINE CONTROL	V6			√	√	√	√		
		V6 OBD			√	√	√			
	AUTOMATIC TRANSAXLE				√	√	√	√		
	ANTI-LOCK BRAKE SYSTEM	ABS			√	√	√	√		
		ABS/ETC(DISABLE)			√	√	√			

## Daewoo **V26.30** Diagnostics List(Note:For reference only)

Vehicles	System	Sub System	Sub System	functions						
				System Info.	Read Dtc	Clear Dtc	Data Stream	Actuation	System ID	Special Functions
	SRS-AIRBAG				√	√	√			
	BODY CONTROL SYSTEM	INSTRUMENT			√	√	√			
		TRIP COMPUTER			√	√	√			
		INSTRUMENT - CONFIG			√	√	√			
WINSTORM/CAPTIVA/ANTABA	ENGINE CONTROL	01.ECM(DIESEL)			√	√	√			LEARNING DATA RESET
		02.2.4 DOHC(GASOLINE)			√	√		√		
		03.3.2 DOHC(GASOLINE)			√	√		√		
	AUTOMATIC TRANSAXLE	TCM(AISIN CAN)			√	√	√			LEARNING DATA RESET
	CHASSIS	01.ABS			√	√		√		SAS SENSOR ZERO SETTING
		02.TCCM			√	√	√	√		
	BODY	BCM			√	√	√	√		

(\*) :Tested;

(?) :Manual on website([www.x431.com](http://www.x431.com))

Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.



<b>CONNECTOR</b>	<b>X431</b>	<b>DIAGUN</b>
SMART OBD	Use for the cars of 16-PIN Diagnostic socket	N/A
DAEWOO-12	Use for the cars of 12PIN Diagnostic socket	Use for the cars of 12PIN Diagnostic socket
OBD 16C	N/A	N/A
CANBUS II	N/A	N/A
diagun connector	N/A	Use for the cars of 16-PIN Diagnostic socket
SUPER 16	Use for the cars of 16-PIN Diagnostic socket	N/A