Vehicle	Systems	Year	Functions						
			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
FORESTER	Engine Control System	before 2010		√	√	√		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode 4.Maintenance mode 5.Injector or Engine Replacement	
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√		1.Function check 2.Freeze Frame	
	SRS Control System	before 2010		√	√	√			
	Integ.unit mode	before 2010		√	√	√		1.Function Check Sequence 2.Integ.Unit customizing	
	Impact_Sensor	before 2010						1.Sensitivity Adjustment Mode	
	Air_Condition_System	before 2010		√	√	√			
	Air_Suspension_System	before 2010		√	√	√		1.Compulsory Height Control	
	Tire_pressure_monitor	before 2010		√	√	√			
	CAN_System	before 2010		√				1.Fault Location	
	Occupant_Detection_System	before 2010						1.Re-Zeroing	

SUBARU **V21.40**Diagnostics List(Note:For reference only)

SUBARU **V21.40** Diagnostics List (Note:For reference only)

Vehicle	Systems	Year	Functions						
			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	Keyless_access_system	before 2010		√	√	√		1.Collation ECM output cheak 2.Power supply ECM output cheak	
IMPREZA	Engine Control System	before 2010		√	√	√		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode 4.Maintenance mode 5.Injector or Engine Replacement	
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√		1.Function check 2.Freeze Frame	
	SRS Control System	before 2010		√	√	√			
	Integ.unit mode	before 2010		√	√	√		1.Function Check Sequence 2.Integ.Unit customizing	
	Impact_Sensor	before 2010						1.Sensitivity Adjustment Mode	
	Air_Condition_System	before 2010		√	√	√			
	Air_Suspension_System	before 2010		√	√	√		1.Compulsory Height Control	
	Tire_pressure_monitor	before 2010		√	√	√			

Vehicle	Systems	Year	Functions						
			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	CAN_System	before 2010		√				1.Fault Location	
	Occupant_Detection_System	before 2010						1.Re-Zeroing	
	Keyless_access_system	before 2010		√	√	√		1.Collation ECM output cheak 2.Power supply ECM output cheak	
LEGACY	Engine Control System	before 2010		√	√	√		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode 4.Maintenance mode 5.Injector or Engine Replacement	
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√		1.Function check 2.Freeze Frame	
	Cruise Control System			√		√			
	SRS Control System	before 2010		√	√	√			
	Integ.unit mode	before 2010		√	√	√		1.Function Check Sequence 2.Integ.Unit customizing	
	Impact_Sensor	before 2010						1.Sensitivity Adjustment Mode	
	Air_Condition_System	before 2010		√	√	√			

SUBARU **V21.40**Diagnostics List(Note:For reference only)

Vehicle	Systems	Year	Functions						
			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	Air_Suspension_System	before 2010		√	√	√		1.Compulsory Height Control	
	Tire_pressure_monitor	before 2010		√	√	√			
	CAN_System	before 2010		√				1.Fault Location	
	Occupant_Detection_System	before 2010						1.Re-Zeroing	
	Keyless_access_system	before 2010		√	√	√		1.Collation ECM output cheak 2.Power supply ECM output cheak	
	Engine Control System	before 2010		√	√	√		1.System Running Check Mode 2.Diagnosis Results 3.Dealer Check Mode 4.Maintenance mode 5.Injector or Engine Replacement	
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√		1.Function check 2.Freeze Frame	
	Cruise Control System			√		√			
OUTBACK	Integ.unit mode	before 2010		√	√	√		1.Function Check Sequence 2.Integ.Unit customizing	

SUBARU V21.40 Diagnostics List (Note:For reference only)

SUBARU V21.40 Diagnostics List (Note:For reference only)

Vehicle	Systems	Year	Functions						
			Sys. Info.	Read code	Clear code	Data stream	Actuation	Special functions	Others
	Impact_Sensor	before 2010						1.Sensitivity Adjustment Mode	
	Air_Condition_System	before 2010		√	√	√			
	Air_Suspension_System	before 2010		√	√	√		1.Compulsory Height Control	
	Tire_pressure_monitor	before 2010		√	√	√			
	CAN_System	before 2010		√				1.Fault Location	
	Occupant_Detection_System	before 2010						1.Re-Zeroing	
	Keyless_access_system	before 2010		√	√	√		1.Collation ECM output cheak 2.Power supply ECM output cheak	
R2	Engine Control System	before 2010		√	√	√			
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√			
	Electric Power steering			√	√	√			
PLEO	Engine Control System	before 2010		√	√	√			
	AT	before 2010		√	√	√			
	Brake Control System	before 2010		√	√	√			
	Electric Power steering			√	√	√			
VIVIO	Engine Control System	before 2010		√	√	√			

(*):Tested;
(?):Manual on website(www.x431.com)
Note:The final interpretation of the products belongs to LAUNCH TECH CO.,LTD.

CONNECTOR	X431	DIAGUN
SMART OBD	N/A	N/A
OBD 16C	The vehicle with 16 Pin diagnostic socket.	N/A
CANBUS II	N/A	N/A
diagun connector	N/A	The vehicle with 16 Pin diagnostic socket.
SUPER 16	The vehicle with 16 Pin diagnostic socket.	N/A
SUBARU-9	The vehicle with 9 Pin diagnostic socket.	The vehicle with 9 Pin diagnostic socket.